



Part No. Description

- 101 Short screw shaft
- 102 Long screw shaft
- 103 Single row ball bearing
- 104 Support ring
- 105 Double row ball bearing
- 108 Gear wheel
- 110 Nut
- 124 Distance bush
- 130 Shim 0,1 mm
- 131 Shim 0,05 mm
- 132 Key
- 133 Key
- 304 Cover
- 305 Socket screw
- 307 Gasket
- 310 Socket screw
- 312 Studbolt
- 314 Nut

Part No. Description

- 317 Filler cap
- 318 Joint washer
- 320 Gasket
- 342 Drain plug
- 343 Joint washer
- 350 Pump casing
- 352 Cylinder liner
- 373 Socket screw
- 375 Fitted pin
- 376 Fitted pin
- 401 Cover
- 404 Ball bearing cover
- 406 Gearbox
- 407 Cover
- 410 Ball bearing cover
- 411 Oil-level indicator
- 414 Ring
- 418 Ring

Part No. Description

- 433 Tapbolt
- 434 Socket screw
- 435 Socket screw
- 439 Gasket
- 440 Gasket
- 443 Drain plug
- 444 Breather
- 448 Gasket
- 470 Ball bearing cover
- 471 Tapbolt
- 479 Joint washer
- 480 Anti-rotation pin for 702
- 702 Mechanical seal
- 703 O-ring
- 704 Lipseal
- 721 Lipseal
- 725 Bush